

## **SECTION 07 62 00: SHEET METAL FLASHING & TRIM**

### **1. GENERAL**

- A. Review all flashings with Brown independent envelope consultant.
- B. Call for end pans at flashing terminations and identify end pan locations on the drawings.
- C. Do not use surface mounted flashings or reglet attachment of any kind.
- D. Conceal fasteners and expansion joints. Exposed fasteners are not allowed on faces of sheet metal exposed to public view; use hook strips and cleats to attach counter flashings; do not show fasteners penetrating the surface of the flashings.
- E. Plastic flashings, asphalt saturated fabric flashings, and fabric-reinforced metal foil flashings are not acceptable.
- F. Lock joints filled with butyl or sealant are not acceptable.
- G. Do not use "keystone" metal flashings, corrugated flashings, or other systems that avoid soldered joints.