



EN1740 Computer Aided Visualization and Design

Spring 2012

4/17/2012 – Lecture B

Brian C. P. Burke



Last Time:

- Intro to GD&T
- Motion analysis with Pro/E

Tonight:


- Motion analysis with Pro/E



EXERCISE - Motion Analysis

How system rotates the assembly

- Click Define Servo Motor
 - Name it crank
 - Select Motion Axis
 - Click axis on crank shaft (should come up as Connection_1.axis_1)






EXERCISE - Motion Analysis

How system rotate the assembly

- Click Define Servo Motor
 - Click Profile tab
 - Select Velocity as Specification
 - Un-check Current and enter 0 as Initial Position
 - Select Constant as Magnitude
 - Enter 36 as a value
 - Click OK






EXERCISE - Motion Analysis

How system rotate the assembly

- Define a Mechanism Analysis

- Click Mechanism Analysis icon
- Make sure Type is set to Kinematic
- Switch to Motor tab and make sure the crank motor is selected
- Click Run
 - Stuff moves
- Click OK






EXERCISE - Motion Analysis

How system rotate the assembly

- Click Playbacks icon
- Note our results are present
- Click Playback button
 - Animation dialog appears
 - **Click Capture button to export**






EXERCISE - Motion Analysis

How system rotate the assembly

- Click Save Current Set to Disk so analysis will be there when we get back






Motion Analysis

Extended mechanism functionality

- Quantified motion analysis
- Mechanism components
 - Springs
 - Friction Forces
- Assumptions
 - All parts are steel
 - Rotation is 1000rpm






EXERCISE - Motion Analysis

Change the assembly units

- The parts are currently in mm-N-sec and the assembly is in in-lb-sec
- Change the assembly units to match the part
 - Back to Standard Application
 - Edit > Setup > Units > mm-N-sec
 - Set
 - Check Convert dimensions
 - OK






EXERCISE - Motion Analysis

Assign density to each part

- Save the assembly
- Switch the application to Mechanism
- Select the Mass Properties icon






EXERCISE - Motion Analysis

Assign density to each part


- Keep Reference Type as Part
- Select the PISTON part
- Change *Define Properties* by dialog to Density
- Enter
$$7.827\text{e-}9 \text{ tonne/mm}^3$$
- OK
- Repeat the process for the other 2 components





EXERCISE - Motion Analysis


- Go to mechanism model tree in the lower left
- Expand
 - Motors
 - Servo
- Open the *crank* motor we defined previously





EXERCISE - Motion Analysis


- Click the Profile tab





EXERCISE - Motion Analysis

- There are a number of ways to define the motion of the servo motor
- Input variable x is time
- Output variable is q , selected by user in Specification box
- Coefficients are defined by user to specify motion according to the definitions shown right




Magnitude Type	Description	Required Settings
Constant	Use for constant motion.	$q = A$ where $A = \text{Constant}$
Ramp	Use for a constant motion or a profile that changes linearly over time.	$q = A + B \cdot x$ where $A = \text{Constant}$ $B = \text{Slope}$
Cosine	Use to assign a cosine wave value to the motor profile.	$q = A \cdot \cos(360 \cdot x / T + B) + C$ where $A = \text{Amplitude}$ $B = \text{Phase}$ $C = \text{Offset}$ $T = \text{Period}$
SCCA	Use to simulate a cam profile output. SCCA can only be used when Acceleration is chosen as the motion type.	
Cycloidal	Use to simulate a cam profile output.	$q = L \cdot x / T - L \cdot \sin(2 \cdot \pi \cdot x / T) / 2 \cdot \pi$ where $L = \text{Total rise}$ $T = \text{Period}$
Parabolic	Use to simulate a trajectory for a motor.	$q = A \cdot x + 1/2 B(x^2)$ where $A = \text{Linear coefficient}$ $B = \text{Quadratic coefficient}$
Polynomial	Use for generic motor profiles.	$q = A + B \cdot x + C \cdot x^2 + D \cdot x^3$ where $A = \text{Constant term coefficient}$



EXERCISE - Motion Analysis


- Redefine the *crank* motor to be
- Specify Position
 - A=0 (initial angular pos.)
 - B=6000
- Use a Ramp Magnitude
- Select Position and Velocity to graph
- Click graph icon





EXERCISE - Motion Analysis


- Back to the mechanism model tree in the lower left
- Expand Analyses
- RMB on the Analysis we had defined last time





EXERCISE - Motion Analysis


- Drop down Analysis Type
- Note Type differences
 - Kinematic – No mass or force
 - Dynamic – Includes mass and force, non-zero acceleration
 - Static – zero acceleration
- **Set type to Kinematic**
- Note duration definitions
 - Length and Rate – Set speed
 - Length and Frame Count – Set number
 - Rate and Frame Count – Calculate rate





EXERCISE - Motion Analysis


- Set the Length and Frame Count
 - Set End Time to .06
 - Frame Count 101
- Click Run
- Go over to Playbacks and Save Analysis





EXERCISE - Motion Analysis


- Click the Measures tool
- Click Create New Measure tool
- From Measure Definition
- Select Position as Type
- Click on the Servo motor icon on the crankshaft
- Click OK





EXERCISE - Motion Analysis

- Double Click on the Results Set
- Click the Graph icon





EXERCISE - Motion Analysis

Reset position

- In Mechanism Tree expand Motors to find Rotation Axis
- RMB > Edit Definition
- Set Current Position to 0.0
- Done

